

8W-49 OVERHEAD CONSOLE

Component	Page	Component	Page
Ambient Temperature Sensor	8W-49-2	Hands Free Module	8W-49-3
Body Control Module	8W-49-2, 3, 4	Integrated Power Module	8W-49-2
Front Control Module	8W-49-2	Left Power Mirror	8W-49-3
Front Reading Lamps/Switch	8W-49-4	Overhead Console	8W-49-2, 3, 4
Fuse 14	8W-49-2	Powertrain Control Module	8W-49-2
G301	8W-49-4	Rear View Mirror	8W-49-3, 4





