

## 8W-51 REAR LIGHTING

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Backup Lamp Switch . . . . .	8W-51-6	G101 . . . . .	8W-51-6
Battery . . . . .	8W-51-6	G302 . . . . .	8W-51-3, 4, 5, 6
Body Control Module . . . . .	8W-51-2, 3, 4, 5, 6	G303 . . . . .	8W-51-7
Brake Lamp Switch . . . . .	8W-51-2, 5	Integrated Power Module . . . . .	8W-51-2, 3, 5, 6
Center High Mounted Stop Lamp . . . . .	8W-51-7	Left Rear Lamp Assembly . . . . .	8W-51-2, 4, 5, 6
Front Control Module . . . . .	8W-51-2, 5, 6	License Lamp . . . . .	8W-51-7
Fuse 2 . . . . .	8W-51-2, 5	Park Lamp Relay . . . . .	8W-51-2, 5, 6
Fuse 3 . . . . .	8W-51-2, 5, 6	Right Rear Lamp Assembly . . . . .	8W-51-2, 3, 5, 6
Fuse 26 . . . . .	8W-51-2, 5	Trailer Tow Connector . . . . .	8W-51-3, 4













