

## 8W-52 TURN SIGNALS

<b>Component</b>	<b>Page</b>
Body Control Module . . . . .	8W-52-2, 3, 4, 5
Fuse 24 . . . . .	8W-52-5
G102 . . . . .	8W-52-2
G200 . . . . .	8W-52-2, 3
G302 . . . . .	8W-52-4
Instrument Cluster . . . . .	8W-52-5
Instrument Panel Switch Bank . . . . .	8W-52-2, 3
Integrated Power Module . . . . .	8W-52-2, 3, 5
Left Front Park/Turn Signal Lamp . . . . .	8W-52-2

<b>Component</b>	<b>Page</b>
Left Rear Lamp Assembly . . . . .	8W-52-4
Left Repeater Lamp . . . . .	8W-52-5
Left Turn Signal Lamp . . . . .	8W-52-3
Multi-Function Switch . . . . .	8W-52-2, 3
Right Front Park/Turn Signal Lamp . . . . .	8W-52-2
Right Rear Lamp Assembly . . . . .	8W-52-4
Right Repeater Lamp . . . . .	8W-52-5
Right Turn Signal Lamp . . . . .	8W-52-3
Trailer Tow Connector . . . . .	8W-52-4

## EXCEPT EXPORT









