

8W-60 POWER WINDOWS

Component	Page	Component	Page
Accessory Relay	8W-60-2	Integrated Power Module	8W-60-2
Driver Power Window Motor	8W-60-3, 4, 6	Left Rear Vent Motor	8W-60-3, 6
Driver Power Window Switch . . .	8W-60-3, 4, 5, 6, 7	Passenger Power Window Motor	8W-60-5, 7
Front Control Module	8W-60-2	Passenger Power Window Switch	8W-60-2, 5, 7
Fuse 28	8W-60-2	Power Window Circuit Breaker	8W-60-2
G300	8W-60-3, 4	Power Window Switch	8W-60-4, 5
G301	8W-60-6	Right Rear Vent Motor	8W-60-3, 6













