

## 8W-62 POWER MIRRORS

<b>Component</b>	<b>Page</b>
Circuit Breaker (JB) . . . . .	8W-62-2
Fuse 2 . . . . .	8W-62-2, 3
Fuse 8 . . . . .	8W-62-4, 7
G306 . . . . .	8W-62-2, 3, 6, 7
Junction Block . . . . .	8W-62-2, 3, 4, 7
Latch-Door-Left Front . . . . .	8W-62-4
Latch-Door-Right Front . . . . .	8W-62-7
Mirror-Inside Rearview . . . . .	8W-62-2, 5
Mirror-Outside Rearview-Driver . . . . .	8W-62-2, 5
Mirror-Outside Rearview-Passenger . . . . .	8W-62-3, 7

<b>Component</b>	<b>Page</b>
Module-Door-Driver . . . . .	8W-62-2, 4, 5, 6, 7
Module-Door-Passenger . . . . .	8W-62-5, 6, 7
Motor-Window-Passenger . . . . .	8W-62-5
Relay-Accessory Delay . . . . .	8W-62-2
Relay-Rear Window Defogger . . . . .	8W-62-2, 3
Switch-Memory Selector . . . . .	8W-62-4
Switch-Mirror . . . . .	8W-62-2, 3, 4
Switch-Window/Door Lock-Driver . . . . .	8W-62-2, 6
Switch-Window/Door Lock-Passenger . . . . .	8W-62-5, 7











