

8W-47 AUDIO SYSTEM

Component	Page
Amplifier-Radio	8W-47-2, 3, 4, 8
Amplifier-Subwoofer	8W-47-8
Antenna-Satellite	8W-47-7
Circuit Breaker-Window/Door Lock	8W-47-8
Clockspring	8W-47-6
Cluster	8W-47-6
Fuse 6	8W-47-2, 7
Fuse 21	8W-47-3
Fuse 48	8W-47-8
G202	8W-47-2, 3, 8
G300	8W-47-8
G301	8W-47-7
Module-Front Control	8W-47-2, 3, 7
Module-Hands Free	8W-47-2

Component	Page
Module-Integrated Power	8W-47-2, 3, 7, 8
Radio	8W-47-2, 3, 5, 7, 8
Receiver-Satellite	8W-47-7
Speaker-Left Front Door	8W-47-4, 5
Speaker-Left Rear	8W-47-4, 5
Speaker-Left Rear Door	8W-47-4, 5
Speaker-Right Front Door	8W-47-4, 5
Speaker-Right Rear	8W-47-4, 5
Speaker-Right Rear Door	8W-47-4, 5
Speaker-Tweeter-Left Front	8W-47-4
Speaker-Tweeter-Right Front	8W-47-4
Switch-Remote Radio-Left	8W-47-6
Switch-Remote Radio-Right	8W-47-6













