

8W-15 GROUND DISTRIBUTION

Component	Page	Component	Page
Amplifier-Radio	8W-15-10	Module-Anti-Lock Brakes	8W-15-2
Amplifier-Subwoofer	8W-15-10, 11	Module-Brake Provision	8W-15-4
Assembly-EGR Valve	8W-15-6	Module-Electronic Overhead	8W-15-8
Backlite-Heated	8W-15-14	Module-Front Control	8W-15-3
Battery	8W-15-2	Module-Fuel Pump	8W-15-3
Cluster	8W-15-8	Module-Hands Free	8W-15-8
Clutch-A/C Compressor	8W-15-6	Module-Heated Seat-Driver	8W-15-12
Control-A/C-Heater	8W-15-7, 9	Module-Heated Seat-Passenger	8W-15-12
Data Link Connector	8W-15-7	Module-Integrated Power	8W-15-3
G100	8W-15-2, 3	Module-Occupant Restraint Controller	8W-15-11
G101	8W-15-3, 4	Module-Powertrain Control	8W-15-5
G102	8W-15-3	Module-Sentry Key Remote Entry	8W-15-7
G103	8W-15-5	Motor-Sunroof	8W-15-9
G105	8W-15-2	Motor-Windshield Wiper	8W-15-4
G106	8W-15-2	Power Outlet-Console	8W-15-12
G107	8W-15-5	Power Outlet-Instrument Panel	8W-15-9
G108	8W-15-6	Pump-Washer-Windshield	8W-15-2
G200	8W-15-7, 8	Radio	8W-15-10
G201	8W-15-9	Receiver-Satellite	8W-15-14
G202	8W-15-10	Relay-Transmission Control	8W-15-3
G300	8W-15-10, 11, 12	Relay-Wiper On/Off	8W-15-3
G301	8W-15-13, 14	Sensor-Brake Fluid Level	8W-15-2
G302	8W-15-14	Sensor-Oxygen-Left Front	8W-15-6
Heater-Cushion Pad-Driver	8W-15-10	Sensor-Oxygen-Left Rear	8W-15-6
Heater-Cushion Pad-Passenger	8W-15-10	Sensor-Oxygen-Right Front	8W-15-6
Lamp-Backup-Left	8W-15-2	Sensor-Oxygen-Right Rear	8W-15-6
Lamp-Backup-Right	8W-15-2	Servo-Speed Control	8W-15-5
Lamp-Center Bezel	8W-15-9	Solenoid-Brake Transmission Shift	8W-15-7
Lamp-Dome-Front	8W-15-9	Switch-Backup Lamp	8W-15-6
Lamp-Dome-Rear	8W-15-9	Switch-Clutch Interlock	8W-15-4
Lamp-Fog-Left Front	8W-15-4	Switch-EVAP System Monitor	8W-15-3
Lamp-Fog-Right Front	8W-15-5	Switch-Headlamp	8W-15-8
Lamp-Headlamp-Left	8W-15-4	Switch-Hood Ajar	8W-15-5
Lamp-Headlamp-Right	8W-15-5	Switch-Ignition	8W-15-7
Lamp-High Mounted Stop	8W-15-14	Switch-Mirror	8W-15-13
Lamp-License-Left	8W-15-4	Switch-Seat Belt-Driver	8W-15-14
Lamp-Park/Turn-Left Front	8W-15-4	Switch-Seat-Driver	8W-15-14
Lamp-Park/Turn-Right Front	8W-15-5	Switch-Stop Lamp	8W-15-8
Lamp-Tail/Stop/Turn-Left	8W-15-2	Switch-Tow/Haul Overdrive Off	8W-15-8
Lamp-Tail/Stop/Turn-Right	8W-15-2	Switch-Transfer Case Selector	8W-15-9
Latch-Door-Left Front	8W-15-11, 13	Switch-Window/Door Lock-Driver	8W-15-13
Latch-Door-Left Rear	8W-15-11, 13	Switch-Window/Door Lock-Driver Express	8W-15-13
Latch-Door-Right Front	8W-15-11, 12	Switch-Window/Door Lock-Passenger	8W-15-12
Latch-Door-Right Rear	8W-15-11	Wiring-Trailer Tow 4-Way	8W-15-14
Mirror-Inside Rearview	8W-15-14	Wiring-Trailer Tow 7-Way	8W-15-14
Mirror-Outside Rearview-Driver	8W-15-13		
Mirror-Outside Rearview-Passenger	8W-15-12		

























