

8W-47 AUDIO SYSTEM

Component	Page	Component	Page
Amplifier Audio	8W-47-4, 5	Remote Radio Switch-Left	8W-47-7
Clockspring	8W-47-7	Remote Radio Switch-Right	8W-47-7
Data Link Connector	8W-47-2, 5	Speaker-Center Instrument Panel	8W-47-4
Fuse 21	8W-47-5	Speaker-Left Front Door	8W-47-3, 6
G201	8W-47-7	Speaker-Left Instrument Panel	8W-47-4
G202	8W-47-2, 5	Speaker-Left Rear	8W-47-3, 6
Hands Free Module	8W-47-2	Speaker-Right Front Door	8W-47-3, 6
Instrument Cluster	8W-47-2, 7	Speaker-Right Instrument Panel	8W-47-4
Integrated Power Module	8W-47-5	Speaker-Right Rear	8W-47-3, 6
Radio	8W-47-2, 3, 4, 7		