



8W-18 BUS COMMUNICATIONS


Component	Page	Component	Page
Amplifier-Radio	8W-18-5, 6	Module-Final Drive Control	8W-18-6
Cluster	8W-18-5	Module-Front Control	8W-18-6
Control-A/C-Heater	8W-18-5	Module-Hands Free	8W-18-6
Data Link Connector	8W-18-2, 3, 4, 5	Module-Integrated Power	8W-18-2, 4, 6
Data Link Connector-Engine	8W-18-4	Module-Occupant Restraint Controller	8W-18-5
Fuse 51	8W-18-2, 4	Module-Powertrain Control	8W-18-2, 3, 6
G120	8W-18-4	Module-Sentry Key Immobilizer	8W-18-6
G201	8W-18-2, 4	Module-Transfer Case Control	8W-18-6
Module-Anti-Lock Brakes	8W-18-6	Radio	8W-18-5
Module-Electronic Overhead	8W-18-5		
Module-Engine Control	8W-18-4, 6		





■ NGC



■ NGC
 ■■ SRT







□ NGC
 □□□ SRT