

8W-35 ALL WHEEL ANTILOCK BRAKES

Component	Page	Component	Page
Fuse 13.....	8W-35-2	Module-Powertrain Control	8W-35-2, 3
Fuse 18.....	8W-35-2	Module-Totally Integrated Power	8W-35-2
Fuse 28.....	8W-35-2	Sensor-Brake Fluid Level	8W-35-2
G104.....	8W-35-2	Sensor-Wheel Speed-ABS-Left Front	8W-35-3
G106.....	8W-35-2	Sensor-Wheel Speed-ABS-Rear.....	8W-35-3
G201.....	8W-35-3	Sensor-Wheel Speed-ABS-Right Front	8W-35-3
Module-Anti-Lock Brakes	8W-35-2, 3	Switch-Stop Lamp	8W-35-3



