

## 8W-39 VEHICLE THEFT SECURITY SYSTEM

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Cluster . . . . .	8W-39-3	Latch-Door-Left Front . . . . .	8W-39-3
Fuse 7 . . . . .	8W-39-2	Latch-Door-Left Rear . . . . .	8W-39-3
Fuse 14 . . . . .	8W-39-2	Latch-Door-Right Front . . . . .	8W-39-3
Fuse 16 . . . . .	8W-39-4	Latch-Door-Right Rear . . . . .	8W-39-3
G200 . . . . .	8W-39-2	Module-Front Control . . . . .	8W-39-2, 4
G300 . . . . .	8W-39-3	Module-Integrated Power . . . . .	8W-39-2, 4
G301 . . . . .	8W-39-3	Module-Powertrain Control . . . . .	8W-39-2
Horn-No. 1 . . . . .	8W-39-4	Module-Sentry Key Remote Entry . . . . .	8W-39-2
Horn-No. 2 . . . . .	8W-39-4	Relay-Horn . . . . .	8W-39-4
Lamp-Headlamp-Left . . . . .	8W-39-4		
Lamp-Headlamp-Right . . . . .	8W-39-4		





