

8W-18 BUS COMMUNICATIONS

Component	Page
Amplifier-Radio	8W-18-3, 4
Cluster	8W-18-3, 4
Control-A/C-Heater	8W-18-3, 4
Data Link Connector	8W-18-2
Fuse 14	8W-18-2
G200	8W-18-2
Module-Anti-Lock Brakes	8W-18-5
Module-Electronic Overhead	8W-18-3, 4
Module-Front Control	8W-18-2, 3, 4, 5

Component	Page
Module-Hands Free	8W-18-3, 4
Module-Integrated Power	8W-18-2
Module-Occupant Classification	8W-18-3, 4
Module-Occupant Restraint Controller . .	8W-18-3, 4
Module-Powertrain Control	8W-18-2, 5
Module-Sentry Key Remote Entry	8W-18-3, 4
Radio	8W-18-3, 4
Receiver-Satellite	8W-18-3, 4









