


## 8W-13 INTEGRATED POWER MODULE

<b>Component</b>	<b>Page</b>
Assembly-Shift Motor/Mode Sensor . .	8W-13-16, 20, 25
Battery . . . . .	8W-13-7
Data Link Connector . . . . .	8W-13-15
Fan Module-Condenser Cooling . . . . .	8W-13-10
Fuse 1 . . . . .	8W-13-7
Fuse 2 . . . . .	8W-13-23
Fuse 7 . . . . .	8W-13-23
Fuse 8 . . . . .	8W-13-13, 14
Fuse 9 . . . . .	8W-13-13
Fuse 10 . . . . .	8W-13-13, 14, 23
Fuse 11 . . . . .	8W-13-12
Fuse 12 . . . . .	8W-13-8, 12
Fuse 13 . . . . .	8W-13-8, 11, 12
Fuse 14 . . . . .	8W-13-8, 11
Fuse 15 . . . . .	8W-13-8, 10
Fuse 16 . . . . .	8W-13-7, 8, 9
Fuse 17 . . . . .	8W-13-8, 11
Fuse 18 . . . . .	8W-13-8, 12, 19
Fuse 19 . . . . .	8W-13-8, 9
Fuse 20 . . . . .	8W-13-8, 12
Fuse 21 . . . . .	8W-13-8, 9
Fuse 22 . . . . .	8W-13-8, 12
Fuse 23 . . . . .	8W-13-8, 10
Fuse 27 . . . . .	8W-13-8, 12, 25
Fuse 28 . . . . .	8W-13-8, 11
Fuse 34 . . . . .	8W-13-25
G113 . . . . .	8W-13-12
G114 . . . . .	8W-13-12, 22, 25
Horn-No. 1 . . . . .	8W-13-9
Horn-No. 2 . . . . .	8W-13-9
Junction Block . . . . .	8W-13-8, 11, 12, 13, 14, 15, 16, 19, 21, 22, 24, 25
Lamp-Fog-Left Front . . . . .	8W-13-10
Lamp-Fog-Right Front . . . . .	8W-13-10
Lamp-Headlamp-Left . . . . .	8W-13-18
Lamp-Headlamp-Right . . . . .	8W-13-18
Lamp-High Mounted Stop . . . . .	8W-13-24
Lamp-License Plate . . . . .	8W-13-14
Lamp-Park/Turn-Left Front . . . . .	8W-13-13, 18
Lamp-Park/Turn-Right Front . . . . .	8W-13-13, 18
Lamp-Side Marker-Left Front . . . . .	8W-13-13
Lamp-Side Marker-Right Front . . . . .	8W-13-13
Lamp-Tail/Stop/Turn-Left . . . . .	8W-13-14, 21, 22, 24
Lamp-Tail/Stop/Turn-Right . . . . .	8W-13-14, 21, 22, 24

<b>Component</b>	<b>Page</b>
Module-Antilock Brakes . . . . .	8W-13-17
Module-Brake Provision . . . . .	8W-13-24
Module-Front Control . . . . .	8W-13-8, 9, 10, 11, 12, 13, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25
Module-Integrated Power . . . . .	8W-13-2, 8, 9, 10, 11, 12, 13, 19, 20, 21, 22, 23, 25
Module-Park Assist . . . . .	8W-13-15
Module-Powertrain Control . . . . .	8W-13-17, 19, 25
Motor-Rear Window Wiper . . . . .	8W-13-11, 16
Motor-Windshield Wiper . . . . .	8W-13-19
Power Distribution Center . . . . .	8W-13-7, 8, 9, 23, 25
Pump-Washer-Windshield . . . . .	8W-13-22
Relay-A/C Clutch . . . . .	8W-13-19
Relay-Accessory Delay . . . . .	8W-13-21
Relay-Adjustable Pedals . . . . .	8W-13-8, 11
Relay-Auto Shut Down . . . . .	8W-13-23
Relay-Blower Motor-Front . . . . .	8W-13-23
Relay-Fog Lamp . . . . .	8W-13-8, 10
Relay-Fuel Pump . . . . .	8W-13-19
Relay-Horn . . . . .	8W-13-8, 9
Relay-Park Lamp . . . . .	8W-13-8, 13
Relay-Radiator Fan High . . . . .	8W-13-8, 10
Relay-Radiator Fan Low . . . . .	8W-13-8, 10
Relay-Rear Window Defogger . . . . .	8W-13-21
Relay-Run/Start . . . . .	8W-13-25
Relay-Starter Motor . . . . .	8W-13-7
Relay-Stop Lamp Inhibit . . . . .	8W-13-24
Relay-Trailer Tow-Left . . . . .	8W-13-8, 9
Relay-Trailer Tow-Right . . . . .	8W-13-8, 9
Relay-Wiper High/Low . . . . .	8W-13-23
Relay-Wiper On/Off . . . . .	8W-13-23
Relay-Wiper Rear . . . . .	8W-13-8, 11
Resistor-Radiator Fan . . . . .	8W-13-10
Sensor-Ambient Air Temperature . . . . .	8W-13-18
Sensor-Brake Fluid Level . . . . .	8W-13-12
Sensor-Washer Fluid Level-Front Rear . . . . .	8W-13-16, 20
Switch-Adjustable Pedals . . . . .	8W-13-11
Switch-Hood Ajar . . . . .	8W-13-25
Switch-Inverter . . . . .	8W-13-20
Switch-Stop Lamp . . . . .	8W-13-16, 24
Transducer-A/C Pressure . . . . .	8W-13-16, 20
Wiring-Trailer Tow 7-Way . . . . .	8W-13-9, 13, 21

## MODULE- INTEGRATED POWER



## FUSES

FUSE NO.	AMPS	FUSED CIRCUIT	FUNCTION
8	10A	L77 20PK/RD	FUSED LEFT INBOARD TAIL LAMP
9	10A	L76 20PK/RD	FUSED PARK LAMP RELAY OUTPUT
10	10A	L78 20WT/OR	FUSED PARK LAMP RELAY OUTPUT
12	20A	INTERNAL	FUSED B(+)
13	20A	INTERNAL	FUSED B(+)
14	20A	INTERNAL	FUSED B(+)
15	20A	INTERNAL	FUSED B(+)
16	20A	INTERNAL	FUSED B(+)
17	20A	INTERNAL	FUSED B(+)
18	20A	INTERNAL	FUSED B(+)
19	20A	INTERNAL	FUSED B(+)
20	20A	INTERNAL	FUSED B(+)
21	20A	INTERNAL	FUSED B(+)
22	30A	INTERNAL	FUSED B(+)
23	40A	INTERNAL	FUSED B(+)
27	30A	A920 14OR/RD	FUSED B(+)
28	30A	A918 14OR/LG	FUSED B(+)

## RELAYS

RELAY-  
ADJUSTABLE  
PEDALS

CAVITY	CIRCUIT	FUNCTION
30	A902 18RD	FUSED B(+)
85	P201 20LG/DB	ADJUSTABLE PEDALS RELAY CONTROL
86	A902 18RD	FUSED B(+)
87	-	-
87A	A85 18RD/LB	ADJUSTABLE PEDALS RELAY OUTPUT

RELAY-FOG  
LAMP

CAVITY	CIRCUIT	FUNCTION
30	A39 18RD/LG	FUSED B(+)
85	L139 20WT/YL	FOG LAMP RELAY CONTROL
86	A39 18RD/LG	FUSED B(+)
87	L89 18WT/YL	FRONT FOG LAMP RELAY OUTPUT
87A	-	-

RELAY-  
HORN

CAVITY	CIRCUIT	FUNCTION
30	A950 18RD	FUSED B(+)
85	X4 20DG/WT	HORN RELAY CONTROL
86	A950 18RD	FUSED B(+)
87	X2 18DG/OR	HORN RELAY OUTPUT
87A	-	-

## RELAYS

RELAY-  
PARK  
LAMP

CAVITY	CIRCUIT	FUNCTION
30	A913 6RD	FUSED B(+)
85	L779 20WT/LB	PARK LAMP RELAY CONTROL
86	A914 6RD	PARK LAMP RELAY OUTPUT
87	A914 6RD	PARK LAMP RELAY OUTPUT
87A	Z385 20BK	GROUND

RELAY-  
RADIATOR  
FAN  
HIGH

CAVITY	CIRCUIT	FUNCTION
30	A16 12RD/BR	FUSED B(+)
85	N112 20DB/OR	HIGH SPEED RADIATOR FAN RELAY CONTROL
86	A16 12RD/BR	FUSED B(+)
87	N23 12DB/DG	HIGH SPEED RADIATOR FAN RELAY OUTPUT
87A	-	-

RELAY-  
RADIATOR  
FAN  
LOW

CAVITY	CIRCUIT	FUNCTION
30	A16 12RD/BR	FUSED B(+)
85	N201 20DB/LG	LOW SPEED RADIATOR FAN RELAY CONTROL
86	A16 12RD/BR	FUSED B(+)
87	N202 12DB/OR	RADIATOR FAN NO. 1 CONTROL
87A	-	-

RELAY-  
TRAILER  
TOW-  
LEFT

CAVITY	CIRCUIT	FUNCTION
30	A911 20RD	FUSED B(+)
85	L655 20WT/OR	LEFT TRAILER TOW BRAKE LAMP RELAY CONTROL
86	A911 20RD	FUSED B(+)
87	L673 18YL	LEFT TRAILER TOW BRAKE LAMP RELAY OUTPUT
87A	-	-

## RELAYS

RELAY-  
TRAILER  
TOW-  
RIGHT

CAVITY	CIRCUIT	FUNCTION
30	A910 20RD	FUSED B(+)
85	L656 20WT/DG	RIGHT TRAILER TOW BRAKE LAMP RELAY CONTROL
86	A910 20RD	FUSED B(+)
87	L674 18LG	RIGHT TRAILER TOW BRAKE LAMP RELAY OUTPUT
87A	-	-

RELAY-  
WIPER  
HIGH/LOW

CAVITY	CIRCUIT	FUNCTION
30	A951 14RD	FUSED B(+)
85	W2 20BR/LG	HIGH/LOW WIPER RELAY CONTROL
86	A5 14RD/VT	FUSED B(+)
87	W4 14BR/OR	FRONT WIPER HIGH/LOW RELAY HIGH SPEED OUTPUT
87A	W3 14BR/WT	FRONT WIPER HIGH/LOW RELAY LOW SPEED OUTPUT

RELAY-  
WIPER  
ON/OFF

CAVITY	CIRCUIT	FUNCTION
30	A951 14RD	FUSED B(+)
85	W5 20BR/LG	ON/OFF WIPER RELAY CONTROL
86	A5 14RD/VT	FUSED B(+)
87	A5 14RD/VT	FUSED B(+)
87A	Z902 14BK	GROUND

RELAY-  
WIPER-  
REAR

CAVITY	CIRCUIT	FUNCTION
30	W13 18LG/BR	REAR WIPER MOTOR CONTROL
85	W12 20BR/OR	REAR WIPER RELAY CONTROL
86	A44 18RD/OR	FUSED B(+)
87	A44 18RD/OR	FUSED B(+)
87A	Z901 18BK	GROUND

