




## 8W - 35 ANTILOCK BRAKES

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Anti-Lock Brake Module . . . . .	8W-35-5, 6, 7	G100 . . . . .	8W-35-2, 5
Body Control Module . . . . .	8W-35-2, 5	G200 . . . . .	8W-35-2, 5
Brake Fluid Level Switch . . . . .	8W-35-3, 6	G300 . . . . .	8W-35-3, 6
Brake Lamp Switch . . . . .	8W-35-3, 6	Integrated Power Module . . . . .	8W-35-2, 3, 5, 6
Clutch Pedal Interlock Switch . . . . .	8W-35-3, 6	Left Front Wheel Speed Sensor . . . . .	8W-35-4, 7
Controller Anti-Lock Brake . . . . .	8W-35-2, 3, 4	Left Rear Wheel Speed Sensor . . . . .	8W-35-4, 7
Engine Control Module . . . . .	8W-35-3, 6	Powertrain Control Module . . . . .	8W-35-3, 6
Front Control Module . . . . .	8W-35-3, 6	Right Front Wheel Speed Sensor . . . . .	8W-35-4, 7
Fuse 9 . . . . .	8W-35-2, 5	Right Rear Wheel Speed Sensor . . . . .	8W-35-4, 7
Fuse 21 . . . . .	8W-35-2, 5	Traction Control Switch . . . . .	8W-35-2, 5
Fuse 26 . . . . .	8W-35-3, 6	Transmission Control Module . . . . .	8W-35-3, 6







- GAS
- DIESEL

