

8W - 60 POWER WINDOWS

Component	Page
Accessory Relay	8W-60-2
Driver Power Window Motor	8W-60-3, 4, 6
Driver Power Window Switch . . .	8W-60-3, 4, 5, 6, 7
Front Control Module	8W-60-2
Fuse 28	8W-60-2
G300	8W-60-3, 4
G301	8W-60-6

Component	Page
Integrated Power Module	8W-60-2
Left Rear Vent Motor	8W-60-3, 6
Passenger Power Window Motor	8W-60-5, 7
Passenger Power Window Switch	8W-60-2, 5, 7
Power Window Circuit Breaker	8W-60-2
Power Window Switch	8W-60-4, 5
Right Rear Vent Motor	8W-60-3, 6











