

8W - 39 VEHICLE THEFT SECURITY SYSTEM

Component	Page	Component	Page
Body Control		Left Sliding Door Control Module	8W-39-8, 9
Module	8W-39-2, 3, 6, 7, 8, 9, 10, 11, 12, 13	Left Sliding Door Latch Sensing Switch . . .	8W-39-8
Clockspring	8W-39-5	Left Sliding Door Lock Motor	8W-39-9
Driver Door Lock Switch	8W-39-11, 12	Left Sliding Door Lock Motor/Ajar	
Front Control Module	8W-39-2, 3, 5	Switch	8W-39-10
Front Intrusion Sensor	8W-39-4	Liftgate Ajar Switch	8W-39-13
Fuse 8	8W-39-5	Liftgate Cinch/Release Motor	8W-39-13
Fuse 14	8W-39-2	Passenger Door Lock Switch	8W-39-11, 12
G102	8W-39-5	Power Liftgate Module	8W-39-13
G200	8W-39-2, 3	Rear Intrusion Sensor	8W-39-4
G300	8W-39-6, 7, 8, 10, 11, 12, 13	Right Cylinder Lock Switch	8W-39-11, 12
G301	8W-39-6, 7, 8, 10, 11, 12	Right Front Door Ajar Switch	8W-39-6
G302	8W-39-13	Right Front Door Lock Motor/Ajar	
G303	8W-39-13	Switch	8W-39-6, 7
High Note Horn	8W-39-5	Right Sliding Door Control Module	8W-39-8, 9
Hood Ajar Switch	8W-39-13	Right Sliding Door Latch Sensing Switch . .	8W-39-8
Horn Relay	8W-39-5	Right Sliding Door Lock Motor	8W-39-9
Horn Switch	8W-39-5	Right Sliding Door Lock Motor/Ajar	
Ignition Switch	8W-39-2, 3	Switch	8W-39-10
Integrated Power Module	8W-39-2, 3, 5	Sentry Key Remote Entry Module	8W-39-2
Left Cylinder Lock Switch	8W-39-11, 12	Siren	8W-39-3
Left Front Door Ajar Switch	8W-39-6	Thatcham Alarm Indicator	8W-39-4
Left Front Door Lock Motor/Ajar		Thatcham Alarm Module	8W-39-3, 4
Switch	8W-39-6, 7		























