




## 8W - 43 OCCUPANT RESTRAINT SYSTEM


<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Belt Tension Sensor .....	8W-43-8	Left Side Impact Sensor 1 .....	8W-43-6
Clockspring .....	8W-43-4	Left Side Impact Sensor 2 .....	8W-43-6
Driver Airbag Squib 1 .....	8W-43-4	Left Side Impact Sensor 3 .....	8W-43-6
Driver Airbag Squib 2 .....	8W-43-4	Occupant Classification Module .....	8W-43-2, 8
Driver Knee Blocker Airbag Squib .....	8W-43-4	Occupant Restraint	
Driver Seat Belt Switch .....	8W-43-3	Controller .....	8W-43-2, 3, 4, 5, 6, 7, 8
Driver Seat Belt Tensioner .....	8W-43-3	Passenger Airbag .....	8W-43-5
Front Control Module .....	8W-43-2, 8	Passenger Airbag On/Off Indicator Lamp ..	8W-43-2
G200 .....	8W-43-2	Passenger Seat Belt Switch .....	8W-43-5
G201 .....	8W-43-2	Passenger Seat Belt Tensioner .....	8W-43-5
G301 .....	8W-43-8	Passenger Seat Weight Sensor .....	8W-43-8
Instrument Cluster .....	8W-43-2	Right Curtain Airbag Squib .....	8W-43-7
Instrument Panel Switch Bank .....	8W-43-2	Right Front Impact Sensor .....	8W-43-7
Integrated Power Module .....	8W-43-2, 8	Right Side Impact Sensor 1 .....	8W-43-7
Left Curtain Airbag Squib .....	8W-43-6	Right Side Impact Sensor 2 .....	8W-43-7
Left Front Impact Sensor .....	8W-43-6	Right Side Impact Sensor 3 .....	8W-43-7











# SIDE AIRBAG

