





8W-47 AUDIO/VIDEO SYSTEM


Component	Page	Component	Page
Amplifier-Radio	8W-47-1, 3, 4	Module-Video Screen	8W-47-6, 7, 8, 9
Antenna-Navigation	8W-47-1	Port-Auxiliary Audio Video	8W-47-8
Antenna-Radio	8W-47-1	Radio	8W-47-1, 2, 9, 10, 11
Antenna-Satellite Radio	8W-47-1	Speaker-Instrument Panel-Center	8W-47-4
Antenna-Satellite Video 1	8W-47-6	Speaker-Instrument Panel-Left	8W-47-2, 4
Antenna-Satellite Video 2	8W-47-6	Speaker-Instrument Panel-Right	8W-47-2, 4
Camera-Rear Video	8W-47-11	Speaker-Left Front Door	8W-47-2, 3
Cluster	8W-47-5	Speaker-Left Rear	8W-47-2, 3
Diagnostic Junction Block	8W-47-1, 7	Speaker-Right Front Door	8W-47-2, 3
Fuse J15 (tipm)	8W-47-1, 6	Speaker-Right Rear	8W-47-2, 3
Fuse M39 (tipm)	8W-47-1	Speaker-Subwoofer	8W-47-4
Fuse M41 (tipm)	8W-47-6	Speaker-Tweeter-Left Rear	8W-47-4
G212	8W-47-1, 6	Speaker-Tweeter-Right Rear	8W-47-4
Mirror-Inside Rearview	8W-47-10	Switch-Horn	8W-47-5
Module-Hands Free	8W-47-10	Switch-Remote Radio-Left	8W-47-5
Module-Satellite Video	8W-47-6, 7	Switch-Remote Radio-Right	8W-47-5
Module-Steering Control	8W-47-5	Switch-Steering Wheel-Right	8W-47-5
Module-Totally Integrated Power	8W-47-1, 6		

















⌘

