

8W-54 TRAILER TOW

Component	Page	Component	Page
Fuse 12	8W-54-1		
Fuse 15	8W-54-2, 3, 4	Switch-Stop Lamp	8W-54-1
Fuse 19	8W-54-1	Wiring-Trailer Tow	8W-54-2
Fuse 26	8W-54-1	Wiring-Trailer Tow	
G106	8W-54-1, 2, 3, 5	4-Way	8W-54-3, 4, 5
Module-Brake Provision	8W-54-1, 2	Wiring-Trailer Tow	
Module-Totally Integrated		7-Way	8W-54-1, 4, 5
Power	8W-54-1, 2, 3, 4		









