

FREQUENTLY ASKED QUESTIONS

[CLICK ON A QUESTION BELOW TO VIEW THE ANSWER:](#)

- **1. PTO Related Questions**
- **2. Where can I pick up the RPM or Vehicle Speed signal?**
- **3. How do I hook up remote start/stop on the Ram trucks?**
- **4. Does Ram sell a remote stop/start kit?**
- **5. Does Ram provide a remote throttle kit?**
- **6. What are the top speeds of the Ram Chassis Cabs?**
- **7. What can I install on the Chassis?**
- **8. How do we become an “approved” upfitter for Ram trucks?**
- **9. Are our 2008 vehicles ARB compliant?**
- **10. What is the new Clean Idle Emission Regulation (details)?**
- **11. What is the Voltage monitoring and auto idle up control?**
- **12. Why are my turn signals blinking at a fast rate?**
- **13. How Do I add to or change my vehicles lighting?**
- **14. I lost my Incomplete Vehicle Document, how can I get a new one?**
- **15. Where can I find information on Weights, Payload and Trailer Tow?**
- **16. What is in the Ambulance Prep package?**
- **17. Where can I find Sprinter Information?**
- **18. Can I retrofit a 2008 or 2009 4500/5500 truck with the factory aluminum wheels?**



FREQUENTLY ASKED QUESTIONS

[CLICK ON A QUESTION BELOW TO VIEW THE ANSWER:](#)

- 1. Can I install a remote throttle device on the Ram truck to use with a PTO application?
- 2. Does Ram provide a remote throttle kit?
- 3. I heard all Ram Chassis Cabs come with PTO capability, is this true?
- 4. What is included in the LBN PTO prep group?
- 5. What is the maximum vehicle speed when mobile mode PTO is active?
- 6. My chassis cab was built without PTO prep. Can it be converted?

➤ ***BACK***

