




TIRE & AXLE DETAIL





CL REAR AXLE SECTION
SHOWING REAR AXLE
IN JOUNCE POSITION

<BASE VEHICLE ONLY>
<SEE TIRE CHART>



CL REAR AXLE SECTION
SHOWING REAR AXLE
IN JOUNCE POSITION



CL REAR AXLE SECTION
SHOWING REAR AXLE
IN JOUNCE POSITION
<BASE VEHICLE ONLY>
<SEE TIRE CHART>