

## Injector-Fuel-No.1 (Diesel)



**INJECTOR-  
FUEL-NO. 1  
(DIESEL)**

INJECTOR-FUEL-NO. 1 (DIESEL) - (ENGINE) 2 WAY

CAV	CIRCUIT	FUNCTION
1	K227 14BK (5.9L)	INJECTOR HIGH SIDE DRIVER-BANK 1
1	K611 14BK (6.7L)	INJECTOR HIGH SIDE DRIVER NO. 1
2	K11 14BK	INJECTOR CONTROL NO. 1

