


Sensor – Fuel Rail Pressure (Diesel)



**SENSOR-
FUEL RAIL
PRESSURE
(DIESEL)**

SENSOR-FUEL RAIL PRESSURE (DIESEL) - (ENGINE) 3 WAY

CAV	CIRCUIT	FUNCTION
1	K915 18BR/WT (5.9L)	FUEL RAIL SENSOR RETURN
1	K916 18BR/OR (6.7L)	SENSOR GROUND
2	K181 18BR/YL	FUEL RAIL SENSOR SIGNAL
3	F855 18PK/YL	5 VOLT SUPPLY

