


## Battery – Positive (Diesel Right Battery)



**BATTERY-  
POSITIVE  
(DIESEL RIGHT BATTERY)**

BATTERY-POSITIVE (DIESEL RIGHT BATTERY) - (BATTERY) 1 WAY

CAV	CIRCUIT	FUNCTION
1	A1 1RD	B(+)
1	A11 8LB	B(+)
1	A19 4BK	B(+)

