


Latch – Door-Left Rear (Base)



LATCH-DOOR-LEFT REAR (BASE) - BLACK (REAR DOOR) 2 WAY

CAV	CIRCUIT	FUNCTION
1	G77 20VT/GY	LEFT REAR DOOR AJAR SWITCH SENSE
2	Z917 20BK	GROUND

Latch – Door-Left Rear (Power Locks)



LATCH-DOOR-LEFT REAR (POWER LOCKS) - BLACK (REAR DOOR) 4 WAY

CAV	CIRCUIT	FUNCTION
1	G77 20VT/GY	LEFT REAR DOOR AJAR SWITCH SENSE
2	Z79 20LG/BK	GROUND
2	Z917 20BK	GROUND
3	P5 18TN/OR	DOOR UNLOCK DRIVER LEFT REAR
4	P393 18LG	DOOR LOCK DRIVER LEFT DOORS


Latch – Door-Right Rear (Base)



LATCH-DOOR-RIGHT REAR (BASE) - BLACK (REAR DOOR) 2 WAY

CAV	CIRCUIT	FUNCTION
1	G76 20VT/GY	RIGHT REAR DOOR AJAR SWITCH SENSE
2	Z72 20LG/BK	GROUND

Latch – Door-Right Rear (Power Locks)



LATCH-DOOR-RIGHT REAR (POWER LOCKS) - BLACK (REAR DOOR) 4 WAY

CAV	CIRCUIT	FUNCTION
1	G76 20VT/GY	RIGHT REAR DOOR AJAR SWITCH SENSE
2	Z72 20LG/BK	GROUND
3	G778 18TN/OR	DOOR UNLOCK DRIVER RIGHT DOORS
4	P392 18LG	DOOR LOCK DRIVER RIGHT DOORS