


## Battery – Positive (Diesel Left Battery)



**BATTERY-  
POSITIVE  
(DIESEL LEFT BATTERY)**

BATTERY-POSITIVE (DIESEL LEFT BATTERY) - (BATTERY) 1 WAY

CAV	CIRCUIT	FUNCTION
1	A0 6RD	B(+)
1	A8 00RD	B(+)
1	A424 16DB	B(+)

