


## Seat Belt – Tension Reducer – Driver (Standard Cab)



**SEAT BELT-  
TENSION  
REDUCER-  
DRIVER  
(STANDARD CAB)**

SEAT BELT-TENSION REDUCER-DRIVER (STANDARD CAB) - (BODY) 2 WAY

CAV	CIRCUIT	FUNCTION
1	F983 20PK/YL	FUSED IGNITION SWITCH OUTPUT (RUN-ACC)
2	R57 20LG/GY	DRIVER SEAT BELT SWITCH SENSE

