


Actuator – Fuel Control (Diesel)



**ACTUATOR-
FUEL
CONTROL
(DIESEL)**

ACTUATOR-FUEL CONTROL (DIESEL) - (ENGINE) 3 WAY

CAV	CIRCUIT	FUNCTION
1	K604 18BR/TN (5.9L)	FUEL CONTROL ACTUATOR DRIVER
1	K365 18DB/BR (6.7L)	FUEL CONTROL ACTUATOR DRIVER
2	K65 18BR/LB (5.9L)	FUEL CONTROL ACTUATOR RETURN
2	K366 18BR/LB (6.7L)	FUEL CONTROL ACTUATOR RETURN

