


Assembly – EGR Valve (Gas)



ASSEMBLY-EGR VALVE (GAS) - BLACK (ENGINE) 6 WAY

CAV	CIRCUIT	FUNCTION
1	K34 20DB/LG	EGR SIGNAL
2	F856 20YL/PK	5 VOLT SUPPLY
3	K900 20DB/DG	SENSOR GROUND
4	Z335 20BK/WT	GROUND
5	-	-
6	K35 20DB/VT	EGR SOL CONTROL

