


Switch – Exhaust Brake



**SWITCH-
EXHAUST
BRAKE**

SWITCH-EXHAUST BRAKE - (INSTRUMENT PANEL) 6 WAY

| CAV | CIRCUIT | FUNCTION |
|-----|--------------|-----------------------------|
| 1 | Z933 20BK/BR | GROUND |
| 2 | E11 200R/DB | PANEL LAMPS DRIVER |
| 3 | G905 20BR/OR | EXHAUST BRAKE SWITCH SIGNAL |
| 4 | V937 20VT/BR | S/C SWITCH RETURN |
| 5 | G904 20VT/DG | EXHAUST BRAKE LAMP SIGNAL |
| 6 | - | - |

