




8W-42 AIR CONDITIONING


Component	Page
Actuator-Blend Door	8W-42-5
Actuator-Blend Door-Driver	8W-42-4
Actuator-Blend Door-Passenger	8W-42-4
Actuator-Mode Door 1	8W-42-4, 5
Actuator-Mode Door 2	8W-42-4, 5
Actuator-Recirculation Door	8W-42-4, 5
Cluster	8W-42-2
Clutch-A/C Compressor	8W-42-6
Control-A/C-Heater	8W-42-2, 3, 4, 5
Fuse 23	8W-42-3
Fuse 33	8W-42-3
G106	8W-42-7


Component	Page
G107	8W-42-6
G120	8W-42-6
G201	8W-42-3
G203	8W-42-2
Module-Engine Control	8W-42-6
Module-Powertrain Control	8W-42-6
Module-Totally Integrated Power	8W-42-2, 3, 6, 7
Motor-Blower	8W-42-2
Motor-Condenser Fan	8W-42-7
Resistor-Blower Motor	8W-42-2
Sensor-Evaporator Temperature	8W-42-3
Transducer-A/C Pressure	8W-42-7











- 6.7L A/T
- ■ EXCEPT 6.7L A/T
- ■ ■ 6.7L DIESEL
- ● ● 5.9L DIESEL

