


## Sensor – Wheel Speed-ABS-Right Front



**SENSOR-  
WHEEL  
SPEED-ABS-  
RIGHT  
FRONT**

SENSOR-WHEEL SPEED-ABS-RIGHT FRONT - (HEADLAMP AND DASH) 2 WAY

CAV	CIRCUIT	FUNCTION
1	B7 20DG/VT	RIGHT FRONT WHEEL SPEED SENSOR (+)
2	B6 20DG/WT	RIGHT FRONT WHEEL SPEED SENSOR (-)

