


## Sensor – Knock No.1 (3.7L/5.7L)



SENSOR-KNOCK NO. 1 (3.7L/5.7L) - BLACK (ENGINE) 2 WAY

CAV	CIRCUIT	FUNCTION
1	K42 20DB/YL	KNOCK SENSOR NO. 1 SIGNAL
2	K942 20BR/LG	KNOCK SENSOR NO. 1 RETURN

