


Sensor – Knock (4.7L)



SENSOR-KNOCK (4.7L) - BLACK (ENGINE) 4 WAY

CAV	CIRCUIT	FUNCTION
1	K942 20BR/LG	KNOCK SENSOR NO. 1 RETURN
2	K42 20DB/YL	KNOCK SENSOR NO. 1 SIGNAL
3	K924 20WT/BR	KNOCK SENSOR NO. 2 RETURN
4	K242 20BR/WT	KNOCK SENSOR NO. 2 SIGNAL

