


## Sensor – Wheel Speed-ABS-Right Rear (ESP)



**SENSOR-  
WHEEL  
SPEED-ABS-  
RIGHT  
REAR  
(ESP)**

SENSOR-WHEEL SPEED-ABS-RIGHT REAR (ESP) - (CHASSIS) 2 WAY

CAV	CIRCUIT	FUNCTION
1	B1 18DG/OR	RIGHT REAR WHEEL SPEED SENSOR (-)
2	B2 18DG/LB	RIGHT REAR WHEEL SPEED SENSOR (+)

