


## Assembly – Transmission Solenoid/Pressure Switch (RLE)



**ASSEMBLY-  
TRANSMISSION SOLENOID/  
PRESSURE SWITCH  
(RLE)**

ASSEMBLY-TRANSMISSION SOLENOID/PRESSURE SWITCH (RLE) - LT. BROWN (ENGINE) 10 WAY

CAV	CIRCUIT	FUNCTION
1	T60 20YL/GY	OD SOLENOID CONTROL
2	T59 20YL/LB	UD SOLENOID CONTROL
3	T16 16YL/OR	TRANSMISSION CONTROL OUTPUT
4	T19 18YL/DB	2-4 SOLENOID CONTROL
5	T47 18YL/DG	2-4 PRESSURE SWITCH SENSE
6	T9 20DG/TN	OD PRESSURE SWITCH SENSE
7	T20 20DG/WT	L/R SOLENOID CONTROL
8	-	-
9	-	-
10	T50 20YL/TN	L/R PRESSURE SWITCH SENSE

