


Sensor – Temperature/Pressure – Map (6.7L)



SENSOR-TEMPERATURE/PRESSURE-MAP (6.7L) - (ENGINE) 4 WAY

CAV	CIRCUIT	FUNCTION
1	K37 18BR	BOOST PRESSURE SENSOR SIGNAL
2	F855 18PK/YL	5 VOLT SUPPLY
3	K21 18DB/LG	INTAKE AIR TEMPERATURE SENSOR SIGNAL
4	K916 18BR/OR	SENSOR GROUND

