


## Sensor – EGR Orifice Temperature (6.7L)



**SENSOR-EGR  
ORIFICE  
TEMPERATURE  
(6.7L)**

SENSOR-EGR ORIFICE TEMPERATURE (6.7L) - (ENGINE) 2 WAY

CAV	CIRCUIT	FUNCTION
1	K914 18BR/WT	SENSOR GROUND
2	K935 18DB	EGR ORIFICE TEMPERATURE SENSOR SIGNAL

