


# Motor – Window – Passenger



MOTOR-WINDOW-PASSENGER - BLACK (FRONT DOOR) 2 WAY

CAV	CIRCUIT	FUNCTION
A	Q22 120R/VT	PASSENGER WINDOW DRIVER DOWN
B	Q12 120R/BR	PASSENGER WINDOW DRIVER UP

