


Assembly – Transmission Solenoid C2 (RC)



**ASSEMBLY-
TRANSMISSION
SOLENOID C2
(RC)**

ASSEMBLY-TRANSMISSION SOLENOID C2 (RC) - (TRANSMISSION) 12 WAY

| CAV | CIRCUIT | FUNCTION |
|-----|--------------|----------------------|
| 1 | T800 20DG/BR | TRX-PRESS SW 1 |
| 2 | T805 20DG/OR | TRX-PRESS SW 6 |
| 3 | T809 20DG/YL | TRX-SOL S2 |
| 4 | T811 20DG/LB | TRX-SOL S4 |
| 5 | T818 20YL/OR | TRX-LINEAR SOL 4 (-) |
| 6 | T814 20YL/BR | TRX-LINEAR SOL 2 (-) |
| 7 | T801 20DG/RD | TRX-PRESS SW 2 |
| 8 | T802 20DG/PK | TRX-PRESS SW 3 |
| 9 | T810 20DG/DB | TRX-SOL S3 |
| 10 | T808 20DG/GY | TRX-SOL S1 |
| 11 | T821 20YL/GY | TRX-LINEAR SOL 4 (+) |
| 12 | T815 20YL/RD | TRX-LINEAR SOL 2 (+) |

