


Sensor – Wheel Speed-ABS-Left Front



**SENSOR-
WHEEL
SPEED-ABS-
LEFT
FRONT**

SENSOR-WHEEL SPEED-ABS-LEFT FRONT - (HEADLAMP AND DASH) 2 WAY

CAV	CIRCUIT	FUNCTION
1	B9 20DG/LG (AWAL)	LEFT FRONT WHEEL SPEED SENSOR (+)
1	B9 18DG/LG (RWAL)	LEFT FRONT WHEEL SPEED SENSOR (+)
2	B8 20DG/TN (AWAL)	LEFT FRONT WHEEL SPEED SENSOR (-)
2	B8 18DG/TN (RWAL)	LEFT FRONT WHEEL SPEED SENSOR (-)

