


## Module – Transmission Control C1 (RC)



**MODULE-  
TRANSMISSION  
CONTROL C1  
(RC)**

MODULE-TRANSMISSION CONTROL C1 (RC) - (HEADLAMP AND DASH) 17 WAY

CAV	CIRCUIT	FUNCTION
1	T52 20DG/OR	INPUT SPEED SENSOR SIGNAL
2	-	-
3	K427 18OR/LG	POWER TAKEOFF RELAY ENABLE
4	-	-
5	T803 20DG/BR	TRX-PRESS SW 4
6	T800 20DG/BR	TRX-PRESS SW 1
7	-	-
8	-	-
9	-	-
10	-	-
11	T804 20YL/DB	TRX-PRESS SW 5
12	T802 20DG/PK	TRX-PRESS SW 3
13	-	-
14	-	-
15	-	-
16	T805 20DG/OR	TRX-PRESS SW 6
17	T801 20DG/RD	TRX-PRESS SW 2

