


Latch – Door-Driver (Base)




**LATCH-
DOOR-
DRIVER
(BASE)**

LATCH-DOOR-DRIVER (BASE) - BLACK (FRONT DOOR) 2 WAY

CAV	CIRCUIT	FUNCTION
1	G75 20VT	DRIVER DOOR AJAR SWITCH SENSE
2	Z917 20BK	GROUND

Latch – Door-Driver (Power Locks)



**LATCH-
DOOR-
DRIVER
(POWER LOCKS)**

LATCH-DOOR-DRIVER (POWER LOCKS) - BLACK (FRONT DOOR) 4 WAY

CAV	CIRCUIT	FUNCTION
1	G75 20VT	DRIVER DOOR AJAR SWITCH SENSE
2	Z917 20BK	GROUND
3	P1 18TN/LG	DOOR UNLOCK DRIVER LEFT FRONT
4	P393 18LG	DOOR LOCK DRIVER LEFT DOORS

