


Module Powertrain Control C3 (NGC)



MODULE-POWERTRAIN CONTROL C3 (NGC) - BLACK/NATURAL (HEADLAMP AND DASH) 38 WAY

CAV	CIRCUIT	FUNCTION
1	-	-
2	-	-
3	K51 20BR/WT	ASD CONTROL
4	-	-
5	V35 20VT/OR (4.7L)	S/C VENT SOL CONTROL
5	K454 20BR/OR (5.7L MDS)	MDS SOL CONTROL NO. 7
6	K451 20BR/WT (5.7L MDS)	MDS SOL CONTROL NO. 1
7	V32 20VT/YL (4.7L)	SPEED CONTROL SUPPLY
8	-	-
9	K299 20BR/WT	O2 1/2 HEATER CONTROL
10	K399 18BR/GY	O2 2/2 HEATER CONTROL
11	C13 20LB/OR	A/C CLUTCH CONTROL
12	V36 20VT/YL (4.7L)	S/C VACUUM SOL CONTROL
13	-	-
14	V32 20VT/YL (3.7L/5.7L)	BRAKE SWITCH NO. 2 SIGNAL
15	V937 20VT/BR (3.7L/5.7L)	S/C SWITCH RETURN
16	K167 20BR/YL (3.7L/5.7L)	APPS NO. 1 RETURN
17	K400 20BR/VT (3.7L/5.7L)	APPS NO. 2 RETURN
18	V38 20VT/OR (3.7L/5.7L)	S/C SWITCH NO. 2 SIGNAL
19	K342 16BR/WT	ASD CONTROL OUTPUT
20	K52 20DB/WT	EVAP PURGE SOL CONTROL
21	T41 20YL/DB	TRS T41 SENSE
22	G113 20VT (4.7L/5.7L EXCEPT UPFITTER)	PTO SENSE
22	G113 18PK/YL (5.7L UPFITTER)	PTO SENSE
23	B29 20DG/WT	BRAKE SWITCH NO. 1 SIGNAL
24	-	-
25	K23 20BR/WT (3.7L/5.7L)	APPS NO. 1 SIGNAL
26	-	-
27	-	-
28	K342 16BR/WT	ASD CONTROL OUTPUT
29	K70 20DB/BR	EVAP PURGE SOL SIGNAL
30	K66 20DB/WT (5.7L)	P/S SWITCH SIGNAL
31	-	-
32	-	-
33	G24 20VT/BR (5.7L)	OIL TEMPERATURE SIGNAL
34	V37 20VT	S/C SWITCH NO. 1 SIGNAL
35	K107 20VT/WT	ESM SIGNAL
36	K29 20WT/BR (3.7L/5.7L)	APPS NO. 2 SIGNAL
37	K31 20BR	FUEL PUMP CONTROL
38	T752 20DG/OR	STARTER SOLENOID CONTROL