


Sensor – Transmission Range (RE)



SENSOR-TRANSMISSION RANGE (RE) - (TRANSMISSION) 6 WAY

CAV	CIRCUIT	FUNCTION
1	-	-
2	T117 20DG/YL	TRANS RANGE SENSOR ELECTRONIC CLUSTER 5 VOLT SUPPLY
3	-	-
4	-	-
5	T917 20YL/TN	TRANS RANGE SENSOR ELECTRONIC CLUSTER 5 VOLT SUPPLY
6	T41 20YL/DB	TRS T41 SENSE

