


## Sensor – Accelerator Pedal Position



**SENSOR-  
ACCELERATOR  
PEDAL  
POSITION**

SENSOR-ACCELERATOR PEDAL POSITION - BLACK (HEADLAMP AND DASH) 6 WAY

CAV	CIRCUIT	FUNCTION
1	F855 20PK/YL (3.7L/5.7L)	5 VOLT SUPPLY
1	K852 20BR/VT (DIESEL)	5 VOLT SUPPLY
2	K23 20BR/WT	APPS NO. 1 SIGNAL
3	K167 20BR/YL	APPS NO. 1 RETURN
4	K400 20BR/VT	APPS NO. 2 RETURN
5	K29 20WT/BR	APPS NO. 2 SIGNAL
6	F856 20YL/PK (3.7L/5.7L)	5 VOLT SUPPLY
6	K854 20VT/BR (DIESEL)	5 VOLT SUPPLY

