


## Motor – Seat Adjuster – Passenger Horizontal



**MOTOR-  
SEAT ADJUSTER-  
PASSENGER  
HORIZONTAL**

MOTOR-SEAT ADJUSTER-PASSENGER HORIZONTAL - (FRONT SEAT) 2 WAY

CAV	CIRCUIT	FUNCTION
1	P16 12LG/BR	PASSENGER SEAT HORIZONTAL REARWARD DRIVER
2	P14 12LG/OR	PASSENGER SEAT HORIZONTAL FORWARD DRIVER

