

## Sensor – Wheel Speed-ABS-Left Rear (ESP)



**SENSOR-  
WHEEL  
SPEED-ABS-  
LEFT  
REAR  
(ESP)**

SENSOR-WHEEL SPEED-ABS-LEFT REAR (ESP) - (CHASSIS) 2 WAY

CAV	CIRCUIT	FUNCTION
1	B3 18DG/YL	REAR WHEEL SPEED SENSOR (-)
2	B4 18DG/GY	REAR WHEEL SPEED SENSOR (+)

