

Starter – Eyelet (Diesel)



**STARTER-
EYELET
(DIESEL)**

STARTER-EYELET (DIESEL) - (BATTERY) 1 WAY

CAV	CIRCUIT	FUNCTION
1	A8 2RD	B(+)

