


## Assembly – Line Pressure Sensor/Variable Force Solenoid (RLE)



**ASSEMBLY-  
LINE PRESSURE  
SENSOR/VARIABLE  
FORCE SOLENOID  
(RLE)**

ASSEMBLY-LINE PRESSURE SENSOR/VARIABLE FORCE SOLENOID (RLE) - BLACK (ENGINE) 6 WAY

CAV	CIRCUIT	FUNCTION
1	-	-
2	F856 20YL/PK	5 VOLT SUPPLY
3	T38 20YL/BR	LINE PRESSURE SENSOR SIGNAL
4	K900 20DB/DG	SENSOR GROUND
5	T16 18YL/OR	TRANSMISSION CONTROL OUTPUT
6	T118 20DG	PRESSURE CONTROL SOLENOID CONTROL

